


# Brockway Model 154WHS

## TRACTOR CHART



Tire Size	BUDD WHEELS						
	H	I	K	L	M	N	
10.00-20	95 <sup>5</sup> / <sub>8</sub> "	71 <sup>1</sup> / <sub>8</sub> "	47 <sup>3</sup> / <sub>4</sub> "	13 <sup>1</sup> / <sub>8</sub> "	10 <sup>1</sup> / <sub>2</sub> "-MIN.	33 <sup>3</sup> / <sub>4</sub> "	
10.00-22	95 <sup>5</sup> / <sub>8</sub> "	71 <sup>1</sup> / <sub>8</sub> "	47 <sup>3</sup> / <sub>4</sub> "	13 <sup>1</sup> / <sub>8</sub> "	11"-MIN.	34 <sup>3</sup> / <sub>4</sub> "	
11.00-20	96"	71 <sup>1</sup> / <sub>8</sub> "	46 <sup>1</sup> / <sub>2</sub> "	13 <sup>3</sup> / <sub>4</sub> "	10 <sup>3</sup> / <sub>4</sub> "-MIN.	34 <sup>1</sup> / <sub>4</sub> "	
CAST SPOKE WHEELS							
10.00-20	95 <sup>1</sup> / <sub>2</sub> "	71 <sup>5</sup> / <sub>8</sub> "	47 <sup>1</sup> / <sub>8</sub> "	13 <sup>1</sup> / <sub>8</sub> "	10 <sup>1</sup> / <sub>2</sub> "-MIN.	33 <sup>3</sup> / <sub>4</sub> "	
10.00-22	95 <sup>1</sup> / <sub>2</sub> "	71 <sup>5</sup> / <sub>8</sub> "	47 <sup>1</sup> / <sub>8</sub> "	13 <sup>1</sup> / <sub>8</sub> "	11"-MIN.	34 <sup>3</sup> / <sub>4</sub> "	
11.00-20	96"	71 <sup>5</sup> / <sub>8</sub> "	46 <sup>1</sup> / <sub>2</sub> "	13 <sup>5</sup> / <sub>8</sub> "	10 <sup>3</sup> / <sub>4</sub> "-MIN.	34 <sup>1</sup> / <sub>4</sub> "	

Wheelbase	CA	B	C	D	E	F	G
144"	69 <sup>1</sup> / <sub>2</sub> "	103 <sup>1</sup> / <sub>2</sub> "	34"	224"	8 <sup>1</sup> / <sub>4</sub> "	5 <sup>3</sup> / <sub>4</sub> "	74 <sup>1</sup> / <sub>2</sub> "

BROCKWAY MOTOR COMPANY, INC.  
 GENERAL OFFICE AND FACTORY  
 CORTLAND, NEW YORK

PRINTED  
 IN  
 U.S.A.